Student name: Zakarya Guerinat

Student ID:217090531

SIT225: Data Capture Technologies

Activity 6.1: Plotly data dashboard

Plotly Dash apps give a point-&-click interface to models written in Python, vastly expanding the notion of what's possible in a traditional "dashboard". With Dash apps, data scientists and engineers put complex Python analytics in the hands of business decision-makers and operators. In this activity, you will learn basic building blocks of Plotly to create Dash apps.

Hardware Required

No hardware is required.

Software Required

Plotly library and Dash module Python 3

Steps

Step	Action				
1	Install Plotly and dash using the command below in the command line.				
	\$ pip install plotly dash				
	You can download Jupyter Notebook from here (https://github.com/deakin-				
	deep-dreamer/sit225/blob/main/week_6/plotly_explore.ipynb) and run all the				
	cells. The Notebook contains multiple sections such as Hello World which				
	follows a sample code in a following cell. If you run the Hello world cell it will				
	show Plotly Dash web page. The cell also includes a Question (#*** Question)				
	which you will need to carry out to get a modified output. You will need to				
	capture the output and share the screenshot in the following steps.				

Question: **Hello World** cell has a question - add another html. Div to show your name, and re-run the cell for output. You will need to update the code, run the cell, capture the screenshot of the output and paste it here.


Hello World Zakarya Guerinat 217090531 SIT225 Week 6 Plotly and Dash

Answer:

Question: Connecting to Data cell has a question - change page size and observe the change in widget controls such as, total number of pages. You will need to update the code, run the cell, capture the screenshot of the output and paste it here.

Answer:


My First App with Data					
country	рор	continent	lifeExp	gdpPercap	
Afghanistan	31889923	Asia	43.828	974.5803384	
Albania	3600523	Europe	76.423	5937.029525999999	
Algeria	33333216	Africa	72.301	6223.367465	
Angola	12420476	Africa	42.731	4797.231267	
Argentina	40301927	Americas	75.32	12779.37964	



Answer: <Your answer>

Question: **Controls and Callbacks** cell has a question - use line graphs instead of histogram. You will need to update the code, run the cell, capture the screenshot of the output and paste it here.

Answer:



Question: Now you have learned how to use Plotly Dash for visualising your data, describe how you will be using this tool for your desired sensor monitoring dashboard with a number of sensors including DHT22 or accelerometer data.

Answer: I will use plotly dash to build a dashboard that shows data from a dht22 sensor, I will show show the change in temperature and humidity, the dashboard will have charts to see how the readings change over time and tables to quickly check the latest values.

Question: Convert the Notebook to PDF and merge with this activity sheet PDF.
You will need this merged PDF to combine with this week's OnTrack task for submission.

Answer: <Your answer>

Week 6 Ontrack Task

```
# app.py
# Plotly Dash Gyroscope Explorer
# - Reads ./gyro_samples_clean.csv from your Week 6 project root
# - Chart type dropdown: Line, Scatter, Histogram, Box (basic + distribution)
# - Axis selector: choose X, Y, Z (any or all)
# - Sample window: enter N samples, page with Prev/Next
# - Summary table updates whenever the graph updates
import os
import pandas as pd
import numpy as np
from dash import Dash, dcc, html, dash_table, Input, Output, State, ctx
import plotly.graph objects as go
import plotly.express as px
CSV_PATH = "./gyro_samples_clean.csv" # keep the CSV in the same folder as app.py
# ----- Load & prepare data -----
if not os.path.exists(CSV PATH):
    raise FileNotFoundError(f"CSV not found at {CSV_PATH}. Put gyro_samples_clean.csv
in the same folder as app.py.")
df_raw = pd.read_csv(CSV_PATH)
# Try to detect timestamp column
time col = None
for cand in ["timestamp", "time", "datetime", "date"]:
    if cand in df raw.columns:
        time col = cand
       break
if time_col is not None:
    # parse to datetime if possible; if it fails, we keep as string
        df_raw[time_col] = pd.to_datetime(df_raw[time_col])
    except Exception:
# Try to detect gyro axis columns (robust to various names)
axis_candidates = {
    "x": ["x", "gx", "gyro_x", "gyroX", "accel_x"],
    "y": ["y", "gy", "gyro_y", "gyroY", "accel_y"],
```

```
axis map = {}
for axis, names in axis_candidates.items():
    for name in names:
       if name in df_raw.columns:
           axis_map[axis] = name
           break
# If nothing found, fall back to the first three numeric columns
if len(axis_map) == 0:
    numeric_cols = [c for c in df_raw.columns if
pd.api.types.is_numeric_dtype(df_raw[c])]
    if len(numeric cols) >= 3:
       axis_map = {"x": numeric_cols[0], "y": numeric_cols[1], "z": numeric_cols[2]}
    elif len(numeric cols) > 0:
        # Partial availability is okay; we'll only show what exists
        for lbl, col in zip(["x", "y", "z"], numeric_cols):
           axis_map[lbl] = col
# Build a working DataFrame with friendly column names
df = df_raw.copy()
for short, real in axis_map.items():
    if short != real and real in df.columns:
       df.rename(columns={real: short}, inplace=True)
# Index column for plotting if no time available
df["sample_idx"] = np.arange(len(df))
# Which axes do we actually have?
available_axes = [a for a in ["x", "y", "z"] if a in df.columns and
pd.api.types.is_numeric_dtype(df[a])]
if len(available_axes) == 0:
    raise ValueError("No numeric X/Y/Z gyro columns found. Ensure your CSV has x,y,z
(or recognizable) numeric columns.")
# ----- Build the app -----
app = Dash(__name__)
app.title = "Gyroscope CSV Explorer"
app.layout = html.Div(
    className="container",
    children=[
       html.H1("Gyroscope CSV Explorer", style={"marginBottom": "0.5rem"}),
       html.Div(
           f"Loaded {len(df)} samples from {os.path.basename(CSV_PATH)}",
           style={"color": "#666", "marginBottom": "1rem"},
```

```
# Controls row
        html.Div(
            style={"display": "grid", "gridTemplateColumns": "1fr 1fr 1fr 0.5fr
0.5fr", "gap": "12px", "alignItems": "end"},
            children=[
                html.Div([
                    html.Label("Chart type"),
                    dcc.Dropdown(
                        id="chart-type",
                        options=[
                            {"label": "Line", "value": "line"},
                            {"label": "Scatter", "value": "scatter"},
                            {"label": "Histogram", "value": "hist"},
                            {"label": "Box (distribution)", "value": "box"},
                        ],
                        value="line",
                        clearable=False,
                ]),
                html.Div([
                    html.Label("Axes (X/Y/Z)"),
                    dcc.Dropdown(
                        id="axes",
                        options=[{"label": ax.upper(), "value": ax} for ax in
available_axes],
                        value=available_axes, # default: show all that exist
                        multi=True,
                    ),
                ]),
                html.Div([
                    html.Label("Samples per page (N)"),
                    dcc.Input(
                        id="n-samples",
                        type="number",
                        min=10, step=10,
                        value=min(500, len(df)), # sensible default
                        debounce=True,
                        style={"width": "100%"},
                    ),
                ]),
                html.Div([
                    html.Label(" "),
                    html.Button("Prev", id="prev-btn", n_clicks=0, style={"width":
"100%"}),
                ]),
                html.Div([
                    html.Label(" "),
```

```
html.Button("Next", id="next-btn", n_clicks=0, style={"width":
"100%"}),
                ]),
        ),
        # Store for paging offset
        dcc.Store(id="page-offset", data=0),
        # Window info
        html.Div(id="window-info", style={"margin": "12px 0", "color": "#444"}),
        # Graph
        dcc.Graph(id="gyro-graph", style={"height": "520px"}),
        # Summary table
        html.H3("Summary of Current Window"),
        dash_table.DataTable(
            id="summary-table",
            style_table={"maxWidth": "720px"},
            style_cell={"textAlign": "center", "padding": "6px"},
            style_header={"fontWeight": "bold"},
        ),
 ----- Helpers -----
def compute_window(df_in, offset, n):
    """Return a slice of df_in from offset to offset+n, clipped to valid range."""
    total = len(df in)
    if total == 0:
        return df_in.iloc[0:0], 0, 0, 0
    n = \max(1, int(n)) if pd.notna(n) else total
    start = max(0, min(int(offset), max(0, total - 1)))
    end = min(total, start + n)
    return df_in.iloc[start:end], start, end, total
def make_summary(df_win, axes, start, end, total):
    """Build a tidy stats table for the selected axes in the current window."""
    rows = []
    for ax in axes:
        if ax in df_win.columns and pd.api.types.is_numeric_dtype(df_win[ax]):
            s = df_win[ax].dropna()
            if len(s) == 0:
                continue
            stats = {
                "Axis": ax.upper(),
                "Count": int(s.count()),
```

```
"Mean": float(s.mean()),
                "Std": float(s.std(ddof=1)) if s.count() > 1 else 0.0,
                "Min": float(s.min()),
                "25%": float(s.quantile(0.25)),
                "Median": float(s.median()),
                "75%": float(s.quantile(0.75)),
                "Max": float(s.max()),
            rows.append(stats)
    meta = f"Showing samples \{start\}-\{end-1\} of \{total\} (window size \{end-start\})"
    return rows, meta
def build_figure(df_win, axes, chart_type):
    """Return a Plotly Figure according to chart type and selected axes."""
    # X-axis: timestamp if available, else sample_idx
    x axis = "sample idx"
    x title = "Sample #"
    if "timestamp" in df_win.columns or "time" in df_win.columns or "datetime" in
df_win.columns or "date" in df_win.columns:
        # choose first available time-like column in the original priority
        for cand in ["timestamp", "time", "datetime", "date"]:
            if cand in df_win.columns:
                x axis = cand
                x_title = cand.capitalize()
                break
    fig = go.Figure()
    if chart_type in ("line", "scatter"):
        mode = "lines" if chart_type == "line" else "markers"
        for ax in axes:
            if ax in df win.columns:
                fig.add_trace(go.Scatter(
                    x=df_win[x_axis],
                    y=df_win[ax],
                    mode=mode,
                    name=ax.upper(),
                ))
        fig.update_layout(
            xaxis_title=x_title,
            yaxis_title="Angular rate / units",
            legend_title="Axis",
            margin=dict(l=40, r=20, t=20, b=40),
    elif chart_type == "hist":
        # Overlaid histograms for each axis
        for ax in axes:
```

```
if ax in df win.columns:
                fig.add_trace(go.Histogram(
                    x=df_win[ax],
                    name=ax.upper(),
                    opacity=0.65,
                ))
        fig.update_layout(
            barmode="overlay",
            xaxis_title="Value",
            yaxis_title="Count",
            legend_title="Axis",
            margin=dict(l=40, r=20, t=20, b=40),
    elif chart_type == "box":
        # Box plots for distribution comparison
        for ax in axes:
            if ax in df_win.columns:
                fig.add_trace(go.Box(
                    y=df_win[ax],
                    name=ax.upper(),
                    boxmean=True
                ))
        fig.update_layout(
            vaxis title="Value",
            margin=dict(l=40, r=20, t=20, b=40),
    return fig
# ----- Callbacks -----
@app.callback(
    Output("page-offset", "data"),
    Input("prev-btn", "n_clicks"),
    Input("next-btn", "n_clicks"),
    Input("n-samples", "value"),
    Input("axes", "value"),
    Input("chart-type", "value"),
    State("page-offset", "data"),
    prevent_initial_call=True
def update_offset(prev_clicks, next_clicks, n_samples, axes, chart_type, offset):
    Paging logic.
    - If Prev/Next clicked: move by N samples.
    - If other controls changed (n, axes, chart type): reset to 0 for a fresh view.
    triggered = ctx.triggered_id
```

```
total = len(df)
    n = max(1, int(n_samples)) if pd.notna(n_samples) else total
    max_start = max(0, total - n)
    if triggered == "prev-btn":
        new_offset = max(0, int(offset or 0) - n)
    elif triggered == "next-btn":
        new_offset = min(max_start, int(offset or 0) + n)
        # Controls changed → reset paging
        new offset = 0
    return int(new_offset)
@app.callback(
    Output("gyro-graph", "figure"),
    Output("summary-table", "data"),
    Output("summary-table", "columns"),
    Output("window-info", "children"),
    Input("chart-type", "value"),
    Input("axes", "value"),
    Input("n-samples", "value"),
    Input("page-offset", "data"),
def update_outputs(chart_type, axes, n_samples, offset):
    # normalize axes input (could be None or single str)
    if axes is None:
        axes = []
    if isinstance(axes, str):
        axes = [axes]
    axes = [a for a in axes if a in available_axes]
    if not axes:
        # Fall back to at least one axis
        axes = available_axes[:1]
    df_win, start, end, total = compute_window(df, offset or 0, n_samples)
    fig = build_figure(df_win, axes, chart_type)
    rows, meta = make_summary(df_win, axes, start, end, total)
    columns = [{"name": k, "id": k} for k in (rows[0].keys() if rows else ["Axis",
"Count", "Mean", "Std", "Min", "25%", "Median", "75%", "Max"])]
    return fig, rows, columns, meta
if __name__ == "__main__":
    app.run(debug=True)
```

The app loads **gyro_samples_clean.csv** from the project root and tries to auto-detect gyro columns for X/Y/Z .It also detects a timestamp column if present; otherwise it uses a running sample index as the x-axis. The layout shows controls for Chart type, Axis selection (X/Y/Z), Window size (N samples), and Prev/Next buttons, a live graph, and a summary table. A hidden dcc. Store keeps the current page offset so the app can page through the dataset in stable windows.

A single callback slices the data into a window and builds a Plotly figure:

Line and Scatter: adds one trace per selected axis vs. time (or sample index).

Histogram: overlays distributions of selected axes within the current window.

Box: adds one box per axis to compare spread/median/outliers.

Axis labels and legends are automatically set; if a timestamp column exists, it's used as the x-axis.

Chart type, axis selection, and N samples recalculate and draw the graph and reset paging to the first window for clarity. The summary table calculates descriptive stats (count, mean, std, min/max, quartiles) for the currently displayed data, so it always matches the graph.

https://deakin.au.panopto.com/Panopto/Pages/Viewer.aspx?id=5453c808-9077-426c-9091-b3460064965b